

WF7552S9(M/W/V/S/C/R) WF7754S9(M/W/V/S/C/R)
WF7550S9(M/W/V/S/C/R) WF7752S9(M/W/V/S/C/R)
WF7558S9(M/W/V/S/C/R) WF7750S9(M/W/V/S/C/R)
WF7502S9(M/W/V/S/C/R) WF7758S9(M/W/V/S/C/R)
WF7500S9(M/W/V/S/C/R) WF7654S9(M/W/V/S/C/R)
WF7508S9(M/W/V/S/C/R) WF7652S9(M/W/V/S/C/R)
WF7400S9(M/W/V/S/C/R) WF7650S9(M/W/V/S/C/R)
WF7408S9(M/W/V/S/C/R) WF7658S9(M/W/V/S/C/R)

Washing Machine user manual

imagine the possibilities

Thank you for purchasing a Samsung product.
To receive a more complete service,
please register your product at
www.samsung.com/global/register



features

- **Silver Wash**

Samsung's silver Nano feature uses silver nano particles to sanitize and disinfect your laundry and your machine's drum. Delicates as well as smelly socks will get odor-free from human sweat at temperature as low as 30°C. That saves energy and protects color and shape of your clothes.

- **Child Lock**

The Child Lock function keeps curious little hands out of the washer. This safety feature ensures, that children do not toy with the operation of the washer. It also alerts you when it is activated.

- **Handwash**

Clothes susceptible to damage, such as those made of linen or silk, can be washed just as if they were being washed by hand.

- **Delay Start**

This function enables users to delay the washing machine's starting time for up to 24 hours.

safety information




Throughout this manual, you'll see Warning and Caution notes.

These warnings, cautions, and the important safety instructions that follow do not cover all possible conditions and situations that may occur.


It's your responsibility to use common sense, caution, and care when installing, maintaining, and operation your washer. Samsung is not liable for damages resulting from improper use.

IMPORTANT SAFETY SYMBOLS AND PRECAUTIONS

What the icons and signs in this user manual means:

 WARNING	Hazards or unsafe practices that may result in severe personal injury or death .
 CAUTION	Hazards or unsafe practices that may result in minor personal injury or property damage .
 CAUTION	To reduce the risk of fire, explosion, electric shock, or personal injury when using your washer, follow these basic safety precautions:

BEFORE USING THE APPLIANCE

 Packing materials can be dangerous to children; keep all packing material (plastic bags, polystyrene, etc.) well out of the reach of children.


The appliance is designed for home use only.

Make sure that water and electrical connections are made by qualified technicians, observing the manufacturer's instructions (see "Installing the Washing Machine") and local safety regulations.

All packaging and shipping bolts must be removed before the appliance is used. Serious damage may occur if they are not removed. See "Removing the shipping bolts".

Before washing clothes for the first time, you must run a complete cycle without clothes. See "Washing for the first time".

SAFETY INSTRUCTIONS

 Before cleaning or carrying out maintenance, unplug the appliance from the electrical outlet or set the Ⓞ (On/Off) button to Off.

Make sure that the pockets of all clothing to be washed are empty.

Hard, sharp objects, such as coins, safety pins, nails, screws, or stones can cause extensive damage to the appliance.

Always unplug the appliance and turn off the water after use.

Before you open the door of the appliance, check that the water has drained. Do not open the door if you can still see water.

Pets and small children may climb into the appliance. Check the appliance before each use.

safety information

The glass door becomes very hot during the washing cycle. Keep children away from the appliance while it is in use.

Do not attempt to repair the appliance yourself. Repairs made by inexperienced or unqualified persons may cause injury and/or make more serious repairs to the appliance necessary.

If the plug (power supply cord) is damaged, it must be replaced by the manufacturer or its service agent or a similar qualified person in order to avoid a hazard.

This appliance should only be serviced by an authorized service center, and only genuine spare parts should be used.

This appliance is not intended for use by young children or infirm persons unless they have been adequately supervised by a responsible person to ensure that they can use the appliance safely. Young children should be supervised to ensure that they do not play with the appliance.

This appliance has to be connected to the plug endurable to proper power consumption.

This appliance has to be positioned so that the plug is accessible after installation.

Do not use processed water containing oil, cream or lotion, which is usually found in skin-care shops or massage clinics.

- Otherwise this will cause the packing to be deformed, which causes a malfunction or water leak.

A stainless washing tube does not usually rust. However if some metal such as a hair pin is left in the tube for an extended time, the tube could rust.

- Do not leave water or bleach containing chlorine in the tube for an extended period of time.
- Do not regularly use or leave water containing iron in the tube for an extended period of time.
- If rust starts appearing on the surface of the tube, apply a cleansing agent (neutral) to the surface and use a sponge or soft cloth to clean it. (Under no circumstances use a metal brush)

For washing machines with ventilation openings in the base, that a carpet must not obstruct the openings.

Use the new hose-sets and old hose-sets should not be reused.

contents


INSTALLING THE WASHING MACHINE	
6	Unpacking the Washing Machine
6	Overview of the washing machine
7	Selecting a location
7	Adjusting the leveling feet
7	Removing the shipping bolts
8	Connecting the water supply hose (Option)
9	Connecting the water supply hose
9	Positioning the drain hose
10	Plugging in the machine
WASHING A LOAD OF LAUNDRY	
11	Overview of the control panel
12	Washing for the first time
13	Putting detergent in the washing machine
13	Washing clothes using Fuzzy Logic
14	Washing clothes manually
14	Using delay start
15	Washing tips and hints
MAINTAINING THE WASHING MACHINE	
16	Draining the washing machine in an emergency
16	Repairing a frozen washing machine
16	Cleaning the exterior
16	Cleaning the detergent drawer and recess
17	Cleaning the debris filter
17	Cleaning the water hose mesh filter
TROUBLESHOOTING	
18	Problems and solutions
18	Understanding error messages
PROGRAMME CHART	
19	Programme chart
APPENDIX	
21	Fabric care chart
21	Electrical warnings
21	Protecting the environment
22	Declaration of conformity
22	Specification

installing the washing machine

UNPACKING THE WASHING MACHINE

Unpack your washing machine and inspect it for shipping damage. Also make sure that you have received all of the items shown below. If the washing machine was damaged during shipping or you do not have all of the items, contact your Samsung dealer immediately.

OVERVIEW OF THE WASHING MACHINE




Wrench



Cold water supply hose



Hose guide



Bolt hole covers

SELECTING A LOCATION

Before you install the washing machine, select a location with the following characteristics:

- A hard, level surface (if the surface is uneven, see “Adjusting the leveling feet,” below)
- Away from direct sunlight.
- Adequate ventilation
- Room temperature that will not fall below 0 °C
- Away from sources of heat such as coal or gas

Make sure that the washing machine does not stand on its power cord.

Ventilation openings must not be obstructed by carpeting when the washing machine is installed on a carpeted floor.

ADJUSTING THE LEVELING FEET

If the floor is uneven, adjust the feet (do not insert pieces of wood or any other objects under the feet):


1. Loosen the leg bolt by turning it with your hand until it is at the desired height.
2. Tighten the locking nut by turning it with the supplied wrench.
 - **Place the washer on a sturdy, flat surface.**
If the washer is placed on an uneven or weak surface, noise or vibration occurs. (Only a 1 degrees angle is allowed.)



REMOVING THE SHIPPING BOLTS

Before using the washing machine, you must remove the five shipping bolts from the back of the unit. To remove the bolts:


1. Loosen all bolts with the supplied wrench before removing them.
2. Take each bolt head and pull it through the wide part of the hole. Repeat for each bolt.
3. Fill the holes with the supplied plastic covers.
4. Keep the shipping bolts for future use.




installing the washing machine

CONNECTING THE WATER SUPPLY HOSE (OPTION)


1. Remove the adaptor from the water supply hose.




2. First, using a '+' type screw driver, loosen the four screws on the adaptor. Next, take the adaptor and turn part(b) following the arrow until there is a 5mm gap.



3. Connect adaptor to the water tap by tightening the screws firmly. Then, turn part (b) following the arrow and put(a) and (b) together.




4. Connect the water supply hose to the adaptor. Pull down part (c) of the water supply hose. When you release part (c) the hose automatically connects to the adaptor making a 'click' sound.




5. Connect the other end of the water supply hose to the inlet water valve at the top of the washer. Screw the hose clockwise all the way in.



- If the water tap has a screw type faucet, connect the water supply hose to the tap as shown.




-  After completing connection, if water leaks from the hose, then repeat the same steps. Use the most conventional type of faucet for water supply. In case the faucet is square or too big, remove the spacing ring before inserting the faucet into the adaptor.

CONNECTING THE WATER SUPPLY HOSE

The water supply hose must be connected to the washing machine at one end and to the water faucet at the other. Do not stretch the water supply hose. If the hose is too short and you do not wish to move the water faucet, replace the hose with a longer, high pressure hose.

To connect the water supply hose:

1. Take the L-shaped arm fitting for the cold water supply hose and connect to the cold water supply intake on the back of the machine. Tighten by hand.



2. Connect the other end of the cold water supply hose to your sink's cold water faucet and tighten it by hand. If necessary, you can reposition the water supply hose at the washing machine end by loosening the fitting, rotating the hose, and retightening the fitting.

Option:

1. Take the red L-shaped arm fitting for the hot water supply hose and connect to the red hot water supply intake on the back of the machine. Tighten by hand.
2. Connect the other end of the hot water supply hose to your sink's hot water faucet and tighten it by hand.
3. Use a Y-piece if you only want to use cold water.




The appliance is to be connected to the water mains using new hose-sets and that old hose-sets should not be used.

POSITIONING THE DRAIN HOSE

The end of the drain hose may be positioned in three ways:

Over the edge of a sink

The drain hose must be placed at a height of between 60 and 90 cm. To keep the drain hose spout bent, use the supplied plastic hose guide. Secure the guide to the wall with a hook or to the faucet with a piece of string to prevent the drain hose from moving.



In a sink drain pipe branch

The drain pipe branch must be above the sink siphon so that the end of the hose is at least 60 cm above the ground.

In a drain pipe

Samsung recommends that you use a 65 cm high vertical pipe; it must be no shorter than 60 cm and no longer than 90 cm.

installing the washing machine

PLUGGING IN THE MACHINE

You **MUST** ground the plug of the washing machine.

Check with a licensed electrician before using the machine to make sure it is properly grounded.

WARNING


Ensure that the plug and power cord are not damaged before use. If you have any reason to remove the moulded plug from this appliance, immediately remove the fuse and dispose of the plug. Do not connect the plug to a mains socket under any circumstances as there is a danger of electric shock.

CIRCUITS


Your washing machine should be operated on a separate circuit from other appliances. Failure to do this may cause the circuit breaker to trip or the fuse to blow.

washing a load of laundry


OVERVIEW OF THE CONTROL PANEL



※ This is a general manual. The INLAY system may be different from that of the product you purchased. For **A**, see item 6 below to select the right specifications that match your product.

<p>1 Digital graphic display</p>	<p>Displays the remaining wash cycle time, all of washing information and error messages.</p>
<p>2 Wash selection button</p>	<p>Press the button to select washing option. it is available only with Cotton, Synthetics, Shirts, Mixed Load, Baby Cotton, Enzyme, Daily Wash program.</p>
<p>3 Temperature selection button</p>	<p>Press the button repeatedly to cycle through the available water temperature options (cold water, 30 °C, 40 °C , 60 °C and 95 °C).</p>
<p>4 Rinse selection button</p>	<p>Press the rinse button to add rinse cycles. Maximum number of rinse cycles is five.</p>
<p>5 Child Lock selection button</p>	<p>This is a button for preventing children from manipulating the washing machine.</p> <p>On/Off - To set the program on: Press the Start/Pause button to turn on the washing machine.</p> <p>Press and hold down the [Rinsing]+[Spin] button for 2-3 seconds. It can only be activated when the machine is turned on. Once you set the Child Lock function while in washing, no button is activated until you set it off. The Child Lock lamp lights on.</p> <p>To set the program off: Press and hold down the [Rinsing]+[Spin] button again for 2-3 seconds, then the lamp lights off and is set off.</p> <p> Check out the Child Lock selection button first when no button is activated while the washing machine is working. To turn the washing machine off urgently when Child Lock function is working, Press and hold down the Start/Pause button for 2-3 seconds.</p>

washing a load of laundry


6 Spin selection button	Press the button repeatedly to cycle through the available spin speed options.	
	WF7754S9/WF7654S9	Rinse hold (☐), No Spin (⊗), 400, 800, 1400 rpm
	WF7752S9/WF7652S9/WF7552S9/WF7502S9	Rinse hold (☐), No Spin (⊗), 400, 800, 1200 rpm
	WF7750S9/WF7650S9/WF7550S9/WF7500S9/WF7400S9	Rinse hold (☐), No Spin (⊗), 400, 800, 1000 rpm
	WF7758S9/WF7658S9/WF7558S9/WF7508S9/WF7408S9	Rinse hold (☐), No Spin (⊗), 400, 800, 800+ rpm
<p>No spin - The laundry remains in the drum without being spun after the final drain</p> <p>Rinse Hold - The laundry remains soaking in the final rinse water.</p> <p>Before the laundry can be unloaded, either "Drain" or the "Spin" program must be run.</p>		
7 Easy Iron button	Press the button to reduce the wrinkles after spinning.	
8 Delay Start selection button	Press the button repeatedly to cycle through the available delayed start options (from 3 hour to 19 hours in one hour increments). Displayed hours means the time of finished washing-cycle.	
9 Silver Nano selection button	Silver Nano water is supplied in washing as well as the last rinse, featuring sterilization and antibacterial coating.	
10 Fuzzy Control dial	Turn the dial to select one of the 14 available wash programs. Turn the dial to "off" to turn the washing machine off. Cotton, Synthetic, Shirts, Delicate Fabrics, Hand Wash For Wool, Silk, Quick, Rinse+Spin, Spin, Drain, Mixed Load, Baby Cotton, Enzyme, Daily Wash	
11 Start/Pause selection button	<p>Press to pause and restart programs.</p> <p>Press the Start/Pause button before adding the laundry. This can only be selected within 5 minutes of the start.</p> <p> If the washing machine power is left on for longer than 10 minutes without any buttons being touched, the power automatically turns off.</p>	

WASHING FOR THE FIRST TIME

Before washing clothes for the first time, you must run a complete cycle without clothes.

To do this:

1. Pour a little detergent into compartment (II) in the detergent drawer.
2. Turn on the water supply to the washing machine.
3. Turn the Fuzzy Control Dial to "Clean Tub"
4. Press the Start/Pause button.
 - This will remove any water from the manufacturer's test run remaining in the machine.



Dispenser ①: Detergent for prewash or starch.

Dispenser ②: Detergent for main wash, water softener, pre-soaking agent, bleach and stain removal product.


Dispenser ③: Additives, e.g. fabric softener or former (fill no higher than lower edge of insert "A")

PUTTING DETERGENT IN THE WASHING MACHINE

1. Pull out the detergent drawer.
2. Add laundry detergent into compartment (II).
3. Add softener into compartment (⊗) (if you desire).
4. Add prewash detergent into compartment (I) (if you desire).



Concentrated or thick fabric softener and conditioner must be diluted with a little water before being poured into the dispenser (prevents the overflow from becoming blocked).



WASHING CLOTHES USING FUZZY LOGIC

Your new washing machine makes washing clothes easy, using Samsung's "Fuzzy Logic" automatic control system. When you select a wash programme, the machine will set the correct temperature, washing time, and washing speed.


To wash clothes using the Fuzzy Logic programs:

1. Turn on your sink's water faucet.
2. Open the door.
3. Load the articles one at a time loosely into the drum, without overfilling.
4. Close the door.
5. Add the detergent, softener, and prewash detergent (if necessary) into the appropriate compartment.



To use prewash detergent, select 'pre' option by pressing 'Wash' button.

6. Turn the Fuzzy Control dial to select the appropriate program for the type of clothes Cotton, Synthetic, Shirts, Delicate Fabrics, Hand Wash For Wool, Silk, Quick, Rinse+Spin, Spin, Drain, Mixed Load, Baby Cotton, Enzyme, Daily Wash. You will see the indicators light up on the control panel.



7. At this time, you can control the washing type, wash temperature, rinsing times, spin speed, delay time by pressing the appropriate option button.
8. Press the Start/Pause button on the Fuzzy Control dial and the wash cycle will begin. The process indicator will light up and the remaining time for the cycle will appear in the display.

When the cycle is finished:

After the total cycle has finished, the power will turn off automatically.

1. Open the door.



The door will not open until 3 minutes after the machine stops or the power turns off. If the door-lock lamp (🔒) turns on and off, please wait until the lamp turns off.

2. Remove laundry.

washing a load of laundry

WASHING CLOTHES MANUALLY

You can wash clothes manually without using the Fuzzy Logic feature.

To do so:

1. Turn the water supply on.
2. Turn the Fuzzy Control dial to “Cotton”
3. Open the door.
4. Load the articles one at a time loosely into the drum, without overfilling.
5. Close the door.
6. Put the detergent and, if necessary, softener or prewash detergent, in the appropriate compartments.
7. Press the Temperature button to select the temperature.
(cold water, 30°C, 40°C, 60°C, 95°C)
8. Press to rinse button to select the required number of rinse cycles.
Maximum number of rinse cycles is six.
The washing duration will be prolonged accordingly.
9. Press the Spin button to select the spin speed.



The rinse hold program allows you to take clothes that are dripping wet out of the washing machine.

☒ : No Spin

☒ : Rinse hold

10. Press the button repeatedly to cycle through the available delayed start options (from 3 hours to 19 hours in one hour increments). Displayed hours means the time of finished washing-cycle.
11. Press the Start/Pause button and the machine will begin the cycle.

USING DELAY START

You can set the washing machine to finish your wash automatically at a later time, choosing from 3 to 19 hours delay (in 1 hour increments). Displayed hours means the time of finished washing-cycle.

To do this:

1. Manually or automatically set your washing machine for the type of clothes you are washing.
2. Press the **Delay Start** button repeatedly until the delay time is set.
3. Press the **Start/Pause** button. The Delay Start indicator (☒) will light, and the clock will begin counting down until it reaches your finish time.
4. To cancel Delay Start, press the Delay button repeatedly until Delay Start light is turned off, or turn the washing machine off. (you can also turn the washing machine off to cancel Delay Start.)

WASHING TIPS AND HINTS

Sorting your laundry: Sort your laundry according to the following characteristics:

- **Type of fabric care label symbol:** Sort laundry into cottons, mixed fibers, synthetics, silks, wools and rayon.
- **Colour:** Divide whites and colours. Wash new, coloured items separately.
- **Size:** Placing items of different sizes in the same load will improve the washing action.
- **Sensitivity:** Wash delicate items separately, using the Delicate wash programme for pure new wool, curtains and silk articles. Check the labels on the items you are washing or refer to the fabric care chart in the appendix.

Emptying pockets: Coins, safety pins and similar items can damage linen, the washing machine drum, and the water tank.

Securing fasteners: Close zippers and fasten buttons or hooks; loose belts or ribbons should be tied together.

Prewashing cotton: Your new washing machine, combined with modern detergents, will give perfect washing results, thus saving energy, time, water and detergent. However, if your cotton is particularly dirty, use a prewash with a protein-based detergent.

Determining load capacity: Do not overload the washing machine or your laundry may not wash properly. Use the chart below to determine the load capacity for the type of laundry you are washing.

Fabric Type	Load Capacity				
	WF7754S9/WF7752S9/ WF7750S9/WF7758S9	WF7654S9/WF7652S9/ WF7650S9/WF7658S9	WF7552S9/ WF7550S9/ WF7558S9	WF7502S9/ WF7500S9/ WF7508S9	WF7400S9/ WF7408S9
Cotton	7.5 kg	6.5 kg	5.5 kg	5.0 kg	4.0 kg
Baby cotton	7.5 kg	6.5 kg	5.5 kg	5.0 kg	4.0 kg
Synthetics	3.0 kg	3.0 kg	2.5 kg	2.5 kg	1.5 kg
Wool	2.0 kg	2.0 kg	1.5 kg	1.5 kg	1.0 kg

Detergent tips: The type of detergent you should use is based on the type of fabric (cotton, synthetic, delicate items, wool), colour, wash temperature, degree and type of soiling.


Always use “low suds” laundry soap, which is designed for automatic washing machines.

Follow the detergent manufacturer’s recommendations based upon the weight of the laundry, the degree of soiling, and the hardness of the water in your area. If you do not know how hard your water is, ask your water authority.

 Keep detergents and additives in a safe, dry place out of the reach of children.

Make sure to insert brassieres (water washable) into a washing net (to be purchased additionally).


- The metal part of brassieres may break through and damage the laundry. Therefore make sure to insert them into a fine washing net.
- Small, light clothing such as socks, gloves, stockings and handkerchiefs can become caught around the entry. Insert them into a fine washing net.




maintaining the washing machine

DRAINING THE WASHING MACHINE IN AN EMERGENCY

1. Unplug the washing machine from the power supply.
2. Open the filter-cover by using a coin or a key.



3. Unscrew the emergency drain cap by turning left. Grip the cap on the end of the emergency drain tube and slowly pull it out about 15 cm.
4. Allow all the water to flow into a bowl.
5. Reinsert the drain tube and screw the cap back on.
6. Replace the filter-cover.



REPAIRING A FROZEN WASHING MACHINE

If the temperature drops below freezing and your washing machine is frozen:




1. Unplug the washing machine.
2. Pour warm water on the source faucet to loosen the water supply hose.
3. Remove the water supply hose and soak it in warm water.
4. Pour warm water into the washing machine drum and let it sit for 10 minutes.
5. Reconnect the water supply hose to the water faucet and check if the water supply and drain operations are normal.

CLEANING THE EXTERIOR

1. Wipe the washing machine surfaces, including the control panel, with a soft cloth and nonabrasive household detergents.
2. Use a soft cloth to dry the surfaces.
3. Do not pour water on the washing machine.

CLEANING THE DETERGENT DRAWER AND RECESS

1. Press the release lever on the inside of the detergent drawer and pull it out.
2. Remove the cap from compartment (⊗).
3. Wash all of the parts under running water.
4. Clean the drawer recess with an old toothbrush.
5. Reinsert the cap (Pushing it firmly into place) and replace the liquid detergent divider into the drawer.
6. Push the drawer back into place.
7. Run a rinse programme without any laundry in the drum.




CLEANING THE DEBRIS FILTER

Clean the debris filter 5 or 6 times a year, or when you see the following error message on the display:

5E

1. Open the filter-cover, see “Draining the washing machine in an emergency” on page 16.
 2. Unscrew emergency drain cap by turning left and drain off all the water.
See “Draining the washing machine in an emergency” on page 16.
 3. Unscrew the filter cap and take it out.
-
4. Wash any dirt or other material from the filter. Make sure the drain pump propeller behind the filter is not blocked.
Replace the filter cap.
 5. Replace the filter-cover.





CLEANING THE WATER HOSE MESH FILTER

You should clean the water hose mesh filter at least one time per year, or when you see the following error message on the display:

4E

To do this:


1. Turn off the water source to the washing machine.
2. Unscrew the hose from the back of the washing machine.
3. With a pair of pliers, gently pull out the mesh filter from the end of the hose and rinse it under water until clean. Also clean the inside and outside of the threaded connector.
4. Push the filter back into place.
5. Screw the hose back onto the washing machine.
6. Turn on the faucet and make sure the connections are watertight.



troubleshooting

PROBLEMS AND SOLUTIONS

PROBLEM	SOLUTION
The washing machine will not start	<ul style="list-style-type: none">• Make sure the door is firmly closed.• Make sure the washing machine is plugged in.• Make sure the water source faucet is turned on.• Make sure to press the Start/Pause button.
No water or insufficient water supply	<ul style="list-style-type: none">• Make sure the water source faucet is turned on.• Make sure the water source hose is not frozen.• Make sure the water intake hose is not bent.• Make sure the filter on the water intake hose is not clogged.
Detergent remains in the detergent drawer after the wash program is complete	<ul style="list-style-type: none">• Make sure the washing machine is running with sufficient water pressure.• Put the detergents in the inner parts of the detergent drawer(away from the outside edges).
Washing machine vibrates or is too noisy	<ul style="list-style-type: none">• Make sure the washing machine is set on a level surface. If the surface is not level, adjust the washing machine feet to level the appliance.• Make sure that the shipping bolts are removed.• Make sure the washing machine is not touching any other object.• Make sure the laundry load is balanced.
The washing machine does not drain and/or spin	<ul style="list-style-type: none">• Make sure the drain hose is not squashed or bent.• Make sure the water hose mesh filter is not clogged.
The Door does not open	<ul style="list-style-type: none">• The door will not open when door-lock light is on.• The door will not open until 3 minutes after the machine stops or the power turns off.



UNDERSTANDING ERROR MESSAGES

ERROR CODE	SOLUTION
dE	<ul style="list-style-type: none">• Close the door.
4E	<ul style="list-style-type: none">• Make sure the source water faucet is turned on.• Check the water pressure.
5E	<ul style="list-style-type: none">• Clean the debris filter.• Make sure the drainage hose is installed correctly.
UE	<ul style="list-style-type: none">• Laundry load is unbalanced; loosen any tangled laundry. If only one item of clothing needs washing, such as a bathrobe or jeans, the final spin result might be unsatisfactory and an "UE" error message will be shown in the display window.
cE/3E	<ul style="list-style-type: none">• Call after-sales service.

Before contacting After-Sales service:

1. Try to remedy the problem (See "Troubleshooting" on this page).
2. Restart the programme to see if the fault is repeated.
3. If the malfunction persists, call after-sales service and describe the problem.

programme chart

PROGRAMME CHART

(● user option)

Programme	Max load (kg)					Detergent and additives				Temp (MAX) °C	Spin speed (MAX) rpm				Delay start	Cycle time (min)
	WF7754S9/ WF7752S9/ WF7750S9/ WF7758S9/	WF7654S9/ WF7652S9/ WF7650S9/ WF7658S9/	WF7552S9/ WF7550S9/ WF7558S9/	WF7502S9/ WF7500S9/ WF7508S9/	WF7400S9/ WF7408S9/	Pre-wash	Wash	Soft-ener	Easy Iron		WF7754S9/ WF7654S9/	WF7752S9/ WF7652S9/ WF7552S9/ WF7502S9/	WF750S9/ WF7650S9/ WF7550S9/ WF7500S9/ WF7400S9/	WF7758S9/ WF7658S9/ WF7558S9/ WF7508S9/ WF7408S9/		
Cotton	7.5	6.5	5.5	5.0	4.0	●	yes	●	●	95	1400	1200	1000	800+	●	90
Synthetic	3.0	3.0	2.5	2.5	2.0	●	yes	●		60	800	800	800	800	●	70
Shirts	3.0	3.0	2.5	2.5	2.0	●	yes	●	yes	60	800	800	800	800	●	45
Delicate Fabrics	3.0	3.0	2.5	2.5	2.0		yes	●		40	800	800	800	800	●	53
Hand Wash For Wool	2.0	2.0	1.5	1.5	1.0		yes	●		40	800	800	800	800	●	39
Silk	2.0	2.0	1.5	1.5	1.0		yes	●		30	400	400	400	400	●	35
Quick	3.0	3.0	2.5	2.5	2.0		yes	●	●	60	1400	1200	1000	800+	●	28

Program	Type of wash
Cotton ⁽¹⁾	Averagely or lightly soiled cottons, bed linen, table linen, underwear, towels, shirts etc.
Synthetic	Lightly or averagely soiled blouses, shirts, etc. Made of polyester(Diolen, Trevira), polyamide(perlon, Nylon) or similar blends.
Shirts	shirts(to iron)
Delicate Fabrics	Delicate curtains, dresses, skirts, shirts and blouses.
Hand Wash For Wool	Only machine washable wollens with pure new wool label.
Silk	Silk shirts, blouses, dresses etc.
Quick	Lightly soiled cottons or linen blouses, shirts, dark coloured terry cloth, coloured linen articles, jeans etc.

(1) EN 60456 test programme

1. The programme duration data has been measured under the conditions specified in Standard IEC 456.
2. Consumption in individual homes may differ from the values given in the table due to variations in the pressure and temperature of the water supply, the load and the type of laundry.

Note for test institutes : For testing in accordance with EN 60456 you must select the Cotton programme and Intensive wash option.

programme chart





























(● user option)

Programme	Max load (kg)					Detergent and additives					Temp (MAX) °C	Spin speed (MAX) rpm				Delay start	Cycle time (min)
	WF7754S9/ WF7752S9/ WF7750S9/ WF7758S9/	WF7654S9/ WF7652S9/ WF7650S9/ WF7658S9/	WF7552S9/ WF7550S9/ WF7558S9/	WF7502S9/ WF7500S9/ WF7508S9/	WF7400S9/ WF7408S9/	Pre-wash	Wash	Soft-ener	Easy Iron	WF7754S9/ WF7654S9/		WF7752S9/ WF7652S9/ WF7552S9/ WF7502S9/	WF7750S9/ WF7650S9/ WF7500S9/ WF7400S9/	WF7758S9/ WF7658S9/ WF7558S9/ WF7508S9/			
Daily Wash	3.0	3.0	2.5	2.5	2.0	●	yes	●	●	40	800	800	800	800	●	58	
Enzyme	3.0	3.0	2.5	2.5	2.0	●	yes	●	●	60	1400	1200	1000	800+	●	100	
Baby Cotton	7.5	6.5	5.5	5.0	4.0	yes	yes	●	●	95	1400	1200	1000	800+	●	105	
Mixed Load	3.0	3.0	2.5	2.5	2.0	●	yes	●		60	800	800	800	800	●	76	
Drain															●	1	
Spin											1400	1200	1000	800+	●	10	
Rinse+Spin								●			1400	1200	1000	800+	●	15	

Program	Type of wash
Daily Wash	Clothes that are washed frequently.
Enzyme	Stained or heavily soiled laundry. (activate enzymes that is contained in the washing-powders.)
Baby Cotton	Averagely or lightly soiled baby(children) cottons, bed linen, table linen, underwear,towels, shirts etc.
Mixed Load	A mix of lightly soiled cottons and synthetic fabrics.
Drain	Just drain the water from washing machine without spinning
Spin	Only spin.
Rinse+Spin	Rinse and spin the laundry without washing.

appendix

FABRIC CARE CHART

	Resistant material		Can be ironed at 100°C max
	Delicate fabric		Do not iron
 	Item may be washed at 95°C		Can be dry cleaned using any solvent
 	Item may be washed at 60°C		Dry clean with perchloride, lighter fuel, pure alcohol or R113 only
 	Item may be washed at 40°C		Dry clean with aviation fuel, pure alcohol or R113 only
 	Item may be washed at 30°C		Do not dry clean
	Item may be hand washed		Dry flat
	Dry clean only		Can be hung to dry
	Can be bleached in cold water		Dry on clothes hanger
	Do not bleach		Tumble dry, normal heat
	Can be ironed at 200°C max		Tumble dry, reduced heat
	Can be ironed at 150°C max		Do not tumble dry

ELECTRICAL WARNINGS

To reduce the risk of fire, electrical shock, and other injuries, keep these safety precautions in mind:

- Operate the appliance only from the type of power source indicated on the marking label. If you are not sure of the type of power supplied to your home, consult your appliance dealer or local power company.
- Use only a grounded or polarized outlet. This plug will fit into the power outlet only one way. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug still doesn't fit, contact your electrician to replace your outlet.
- Protect the power cord. Power supply cords should be routed so that they are unlikely to be walked on or pinched by items placed on or against them. Pay particular attention to cords at plugs, convenience receptacles, and the point where they exit from the unit.
- Do not overload the wall outlet or extension cords. Overloading can result in fire or electric shock.

PROTECTING THE ENVIRONMENT

- This appliance is manufactured from recyclable materials. If you decide to dispose of this appliance, please observe local waste disposal regulations. Cut off the power cord so that the appliance cannot be connected to a power source. Remove the door so that animals and small children cannot get trapped inside the appliance.
- Do not exceed the detergent quantities recommended in the detergent manufacturers' instructions.
- Use stain removal products and bleaches before the wash cycle only when strictly necessary.
- Save water and electricity by only washing full loads (the exact amount depends upon the program used).

appendix

DECLARATION OF CONFORMITY

This appliance complies with European safety standards, EC directive 93/68 and EN Standard 60335.

SPECIFICATION

TYPE		FRONT LOADING WASHER								
DIMENSION	WF7754S9/7752S9/7750S9/7758S9				WF7654S9/7652S9/7650S9/7658S9					
	W598mmXD600mmXH844mm				W598mmXD550mmXH844mm					
WATER PRESSURE		50kpa~800kpa								
WATER VOLUME		60 ℓ				54 ℓ				
NET WEIGHT	WF7754S9/ 7752S9		WF7750S9/ 7758S9		WF7654S9/ 7652S9/		WF7650S9/ 7658S9			
	74 kg		73 kg		72 kg		70 kg			
WASH and SPIN CAPACITY		7.5 kg(DRY LAUNDRY)				6.5 kg(DRY LAUNDRY)				
POWER CONSUMPTION	MODEL		WF7754S9/7752S9/7750S9/7758S9				WF7654S9/7652S9/7650S9/7658S9			
	WASHING AND HEATING		220V		2000W		220V		2000W	
			240V		2400W		240V		2400W	
	SPIN	MODEL	WF7754S9	WF7752S9	WF7750S9	WF7758S9	WF7654S9	WF7654S9	WF7654S9	WF7654S9
		230 V	700W	360W	320W	270W	580W	530W	500W	430W
PUMPING		34W								
PACKAGE Wt	MODEL		WF7754S9/7752S9/7750S9/7758S9				WF7654S9/7652S9/7650S9/7658S9			
	PAPER		2.5Kg				2.5Kg			
	PLASTIC		1.0Kg				1.0Kg			
SPIN REVOLUTION	MODEL		WF7754S9/7654S9				WF7752S9/7652S9/7552S9/7502S9			
	rpm		1400				1200			

TYPE		FRONT LOADING WASHER												
DIMENSIONS		WF7552S9/7550S9/ 7558S9/				WF7502S9/7500S9/ 7508S9/				WF7400S9/7408S9				
		W598mmXD450mm XH844mm				W598mmXD404mm XH844mm				W598mmXD340mmX H844mm				
WATER PRESSURE		50kpa~800kpa												
WATER VOLUME		49 ℓ				48 ℓ				43 ℓ				
NET WEIGHT		WF7552S9/ 7550S9/		WF7528S9		WF7502S9/7500S9/ 7508S9/				WF7400S9/7408S9				
		66 kg		65 kg		61 kg				51 kg				
WASH and SPIN CAPACITY		5.5 kg(DRYLAUNDRY)				5.0 kg(DRYLAUNDRY)				4.0 kg(DRYLAUNDRY)				
POWER CONSUMPTION		MODEL		WF7552S9/7550S9/ 7558S9/				WF7502S9/7500S9/ 7508S9/				WF7400S9/7408S9		
		WASHING AND HEATING		220V		1900W		220V		1800W		220V		1800W
				240V		2200W		240V		2100W		240V		2100W
		SPIN		MODEL		WF 7552S9	WF 7550S9	WF 7558S9	WF 7502S9	WF 7500S9	WF 7508S9	WF7400S9	WF7408S9	
				230 V		550W	500W	430W	270W	230W	180W	230W	180W	
PUMPING		34W												
PACKAGE Wt		MODEL		WF7552S9/7550S9/ 7558S9/				WF7502S9/7500S9/ 7508S9/				WF7400S9/7408S9		
		PAPER		2.1Kg				1.9Kg				1.8kg		
		PLASTIC		0.9Kg				0.8Kg				0.8Kg		
SPIN REVOLUTION		MODEL		WF7750S9/7650S9/7550S9/7500S9/ 7400S9				WF7758S9/7658S9/7558S9/7508S9/ 7408S9						
		rpm		1000				800						



QUESTIONS OR COMMENTS?

Country	CALL	OR VISIT US ONLINE AT
INDIA	3030 8282 1800 110011	http://www.samsung.com/in/
INDONESIA	0800-112-8888	www.samsung.com/id
JAPAN	0120-327-527	www.samsung.com/jp
MALAYSIA	1800-88-9999	www.samsung.com/my
PHILIPPINES	1800-10-SAMSUNG (7267864)	www.samsung.com/ph
SINGAPORE	1800-SAMSUNG (7267864)	www.samsung.com/sg
THAILAND	1800-29-3232 02-689-3232	www.samsung.com/th
TAIWAN	0800-329-999	www.samsung.com/tw
VIETNAM	1 800 588 889	www.samsung.com/vn
CHINA	800-810-5858 , 010- 6475 1880	www.samsung.com.cn
HONG KONG	3698 - 4698	www.samsung.com/hk